

ENR 1.7 Altimeter Setting Procedure

1. General

1.1 The altimeter setting procedures in use are those contained in the Procedures for Air Navigation Services - Aircraft Operations (ICAO DOC 8168 OPS / 611).

1.2 Transition Altitudes

Transition Altitudes have been established for all aerodromes in Greenland as indicated on the Instrument Approach Charts and in AD 2 item 17 and AD 3 item 16, except for Alluitsup Paa, Kangilinnguit and the AD 4 heliports, where no Transition Altitudes have been established.

1.3 Transition Levels

Transition Level will be advised by the appropriate ATS unit, except for Thule CTR, where Transition Level has been established at FL 90.

ENR 1.7 Højdemålerindstilling

1. Generelt

1.1 Fremgangsmåder for indstilling af højdemåler er indeholdt i Procedures for Air Navigation Services - Aircraft Operations (ICAO DOC 8168 OPS / 611).

1.2 Gennemgangshøjder

Gennemgangshøjder er fastsat for alle flyvepladser i Grønland som anført på instrumentindflyvningskortene samt i AD 2 punkt 17 og AD 3 punkt 16, undtagen for Alluitsup Paa, Kangilinnguit og AD 4 helikopterflyvepladserne, hvor der ikke er fastsat nogen gennemgangshøjder.

1.3 Gennemgangsniveauer

Gennemgangsniveau vil blive oplyst af vedkommende lufttrafiktjenesteenhed, undtagen for Thule CTR, hvor gennemgangsniveauet er fastsat til FL 90.